


Wi-Fi® connection guide

You can wirelessly stream music from an iOS device, an Android™ device or a Mac/PC to SC-PMX9DB's speakers. To use this music-streaming feature, SC-PMX9DB must join the same 2.4 GHz wireless network as the compatible device through the wireless network router (access point).



• For information on how to connect with a LAN cable, refer to "Wired LAN connection" in the Operating Instructions.



*1: Refer to the Operating Instructions for the compatibility.
Screen images used in this sheet : iPhone 4S, iOS 6.0.1

Start wireless network settings

- Preparation
- 1 Place SC-PMX9DB close to the wireless network router as possible and then point the antenna on the rear of the main unit up as shown in the figure.
 - Do not tilting the antenna forward or backwards when it is pointing up.
 - 2 Connect the AC mains lead while the LAN cable is disconnected.
 - 3 Turn this system on.
 - 4 Follow the chart below to choose the network setting method.
 - If you want to perform wireless setting with your Mac/PC, or you want to apply the advanced setting, refer to "Method 4" in the operating instructions.



Method 1

- 1 Press [SETUP] on the remote control repeatedly to select "Net Setup" and then press [OK]. "With iPod" is indicated on the display.
 - 2 Press [SETUP] on the remote control repeatedly to select "WPS Push" and then press [OK]. "WPS" flashes on the display.
-
- 3 Press the WPS button on the wireless network router.
-
- The settings are completed when "Success" is displayed and "W" is indicated on the display.
-
- 4 Press [OK] on the remote control to exit.

*2 : The marking may differ.

Method 2

- The following explanations are based on an iPhone.
- 1 Disconnect iPod/iPhone/iPad connected to the main unit.
 - 2 Connect the iPhone to your home wireless network.
-
- 3 Connect the iPhone to the main unit. Choose one of the following connections.
- Lightning connector compatible iPod touch/iPhone:
-
- iPod touch/iPhone/iPad with iOS 5.0 or later:
Dedicated cable supplied with the iOS device
- 4 Press [SETUP] on the remote control repeatedly to select "Net Setup" and then press [OK]. "With iPod" is indicated on the display.
 - 5 Unlock your iPhone and then press [OK] on the remote control.
 - 6 A message will pop-up on the iPhone. Allow the iPhone to share the wireless network settings.
-
- 7 The settings are completed when "Success" is displayed and "W" is indicated on the display.
 - 8 Press [OK] on the remote control to exit.

Method 3

-
- You can make the wireless network settings with the app, "Panasonic Stereo System Network Setup" (for free). If you're using an Android device, download the app at Google Play™. If you're using an iPod touch/iPhone/iPad, download it at the App Store.
- Preparation
- Connect your smartphone to your home wireless network.
 - Check the password for your home wireless network.
- 1 Press [SETUP] on the remote control repeatedly to select "Net Setup" and then press [OK]. "With iPod" is indicated on the display.
 - 2 Press [SETUP] on the remote control repeatedly to select "Manual" and then press [OK].
-
- 3 Start "Panasonic Stereo System Network Setup" on your smartphone and follow the indications.
- Note for the iOS version
- After step 3
- 1 Enter the password for the home wireless network to which the iOS device is connected.
 - 2 When a message instructing you to connect the iOS device to this system is displayed, press the home button.
 - 3 On the Wi-Fi network selection screen in "Settings", select "00 Setup _____".
-
- 4 When a message indicating the completion of the connection to this system is displayed, restart the app.
-
- 5 When a message indicating the completion of the Wi-Fi setup of this system is displayed, close the app, and then check the operation of AirPlay, etc.

Using AirPlay

The following explanations are based on an iPhone.

- AirPlay, the AirPlay logo, iPad, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- App Store is a service mark of Apple Inc.
- Android and Google Play are trademarks of Google Inc.
- The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance.
- The Wi-Fi Protected Setup Mark is a mark of the Wi-Fi Alliance.
- "Wi-Fi" and "Wi-Fi Protected Setup" are marks or registered marks of the Wi-Fi Alliance.
- All other trademarks are trademarks of their respective owners.

